
MAE 106 Post-Laboratory Quiz

Laboratory Exercise #1: Laboratory Tools and Control of a Motor


In Lab 1, you learned how to use the oscilloscope, function generator, breadboard, ohmmeter and potentiometer. You also learned how to use a low power signal, power transistor, and operational amplifier to control the speed of a motor.

25 of 5 1. Match the instrument with its use.

5 a.	Oscilloscope	1. Building circuits		
5 b.	Function generator	2. Controlling a voltage	(b is	0 K.)
< c	Breadhoard	d 3 Measuring a resistance		



Prove that
$$V_{-} = V_{+}$$
 for the following voltage follower circuit, using the fact that $V_{0} = K(V_{+}-V_{-})$ for an op amp, with $K = 10,000$.



Shown below is a 10 K Ω potentiometer wired incorrectly. Assume the potentiometer has a $\frac{1}{4}$ watt power rating (remember power = IV). Assume that $V_{in} = 10$ Volts. When the pot's shaft angle = 0° , then R1 = 0 and R2 = 10 K Ω . When the pot's shaft angle = 180° then R2 = 0 and R1 = 10 K Ω . Assume that you start with the pot angle = 0° , and slowly turn it toward 180°. At what angle will the pot begin to smoke?

